





# Search



## Search by title

1. Select the **Search**  icon from the Quick Menu, then select **Title Search**.
2. Use the ▲▼ buttons on your remote until the first letter of the title you want appears in the first box. Advance to the next box by pressing the ► button.
3. Continue entering letters for the program you are seeking. Press  to jump to the listings below. Highlight your program and press .

## Search by category or channel

- Select the **Search**  icon from the Quick Menu.
  - Select a category such as **Movies**, **Sports**, **Kids**, or **HDTV** from the Search Menu.
- OR —
- Select **TV Listings by Channel** and press the ◀▶ buttons to see a list of programs for the next channel, or enter the channel number.